

St. Louis Woodworkers Guild  
Dinette Table Cut List

<b>Part</b>	<b>Material</b>	<b>Deminsions</b>	<b>Quantity</b>
Leg Blank	4/4 Poplar	4-1/2" x 30"	4
Apron	4/4 Poplar	4" x 22"	4
Corner Bracket	4/4 Poplar	3-1/2" x 7-1/8"	4
Corner Block	4/4 Poplar	2-1/4" x 2-1/4" x 3-1/2"	4
Kreg Screws - Apron		Fine Thread 1-1/4 (see Notes #7)	24
Kreg Screws - Corner Brace		Fine Thread 1-1/4 (see Notes #7)	24
Lag Screw - Corener Brace		1/4" x 2-1/2"	4

*Notes:*

- 1.) *Cut Leg Blanks at 45 degs. on an aprox. 9- deg. taper. The two cut pieces are glued and nailed together on their 45 deg. chamfer to make one leg assembly.*
- 2.) *Fasten Apron to leg assemblies using three pocket hole screws and glue at each joint.*
- 3.) *Glue up scrap Poplar to 2-1/4" thick to use for corner blocks.*
- 4.) *Glue and nail corner blocks to top of leg assemblies.*
- 5.) *Fit corner braces to corner blocks and aprons.*
- 6.) *Pre-drill hole for lag screw. Glue and screw corner braces to to corner block.*
- 7.) *The length of the Kreg screw will depend on your pocket-hole jig settings.*